

DINSYNC
MIX IN
MIDI IN
MIDI THRU
MIDI OUT
MIX OUT
USB
CV
GATE
PHONE
9VAC/PWR
TUNE
CUTOFF
RESONANCE
ENV MOD
DECAY
ACCENT
TEMPO
PATTERN (SYNC OUT)
MIDI PLAY
RANDOM
KEYBOARD
PAT. EDIT (MIDI)
USER B
USER C
BOOTLOAD
COMPUTER CONTROL
PATTERN (DINSYNC)
PATTERN (MIDISYNC)
PATTERN EDIT
TRACK (SYNC OUT)
TRACK (DINSYNC)
TRACK (MIDISYNC)
TRACK EDIT
TRANSISTORIZE THE WORLD
VOLUME
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16
C C# D D# E F F# G G# A A# B C´
1 2 3 4 5 6 7 8
PREV
NEXT
RUN
CHAIN
DOWN
UP
DONE
REST
ACCENT
SLIDE